

All Atom Setup

- Load your protein (+ coordinated ions..) PDB of choice into VMD
- Extensions → Modeling → **Automatic PSF Builder**
 - Click “Load Input Files”. (Default input files are almost always OK)
 - Select ‘Everything,’ and click “Guess and split chains using current selection”
 - Look at the segments it created for you. Make any changes
 - I usually rename them to simplify things down the line (i.e., “AP1” > “A”)
 - Also make sure there’s no overlap in chain name. (If there is, fix that in your starting PDB with Phenix and start over)
 - Click “create chains,” and accept the popups.
 - Check that the patches make sense, if any.
 - Click “Apply patches and finish PSF/PDB”
 - **OUTPUT:** yourfile_autopsf.pdb, yourfile_autopsf.psf
- Extensions → Modeling → **Add Solvation Box**
 - Uncheck “waterbox only,” if needed, and make sure your outputs (above) are loaded
 - Change “output” to yourfile_S
 - Check “rotate to minimize volume,” and “Use Molecule Dimensions”
 - Add a reasonable padding to your molecule. For me, 12.5Å in all boxes
 - Click Solvate. **OUTPUT:** yourfile_S.pdb, yourfile_S.psf
- Extensions → Modeling → **Add Ions**
 - Make sure your outputs are loaded. Change “output” to “yourfile_SI”
 - Select salt of choice (for me, KCl for cytosolic).
 - Select “Neutralize and set xxx concentration to ...” and your conc of choice (for me, 0.1M).
 - Click “Autoionize.” **OUTPUT:** yourfile_SI.pdb, yourfile_SI.psf
- Center your molecule in 3D space and measure your box boundaries
 - Extensions → **Tk Console**. Make sure yourfile_SI.psf is the “T” top molecule selected
 - Type “set sel [atomselect top all]”, enter
 - Type “set coords [measure center \$sel]”, enter
 - Type “\$sel moveby [vecinvert \$coords]”, enter
 - Type “\$sel writpdb yourfile_SIC.pdb”, enter
 - Type “measure minmax \$sel”
 - Add the absolute value of each coordinate together. Round to the nearest number
 - In terminal, open yourfile-min.conf in a text editor, i.e. “vim yourfile-min.conf”
 - Use rounded numbers for the cellBasisVector X, Y, Z measurements of the periodic boundary conditions. cellOrigin remains 0.00, 0.00, 0.00. Save and exit editor.
- Back in VMD, Restrain your protein backbone from moving during minimization
 - Load your centered pdb file, yourfile_SIC.pdb, from above
 - File → New molecule, browse → yourfile_SIC.pdb → Load
 - Extensions → **Tk Console**
 - Type “set sel [atomselect top “protein and backbone”]”, enter
 - Type “\$sel set beta 10”
 - Type “set sel [atomselect top all]”
 - Type “\$sel writpdb yourfile_SICR.pdb”

Close VMD

Minimization

- Collect necessary files
 - **Input files:** yourfile_SICR.pdb, yourfile_Sl.psf
 - **Minimization config file**, named yourfile-min.conf
 - **Parameters:** par_all35m_prot.prm, toppar_water_ions.str
 - **Submit files:** min-job-submit.sbatch
- Edit config file
 - Change blurb at top to describe your experiment, including date and molecule and goal
 - Change Input files to match yours:
 - coordinates yourfile_SICR.pdb
 - structure yourfile_Sl.psf
 - Change Output Controls / outputname to yourfile-min
 - Change restraint setup / Consref and restraint setup/ConsKFile to yourfile_SICR.pdb
 - Set periodic boundary conditions appropriately
 - *****UPDATE THIS GUIDANCE!*****
 - Take minmax of the SIC pdb. Add absolute value of each coord X, Y, Z and round up to the nearest whole number.
 - Set cell origin = 0
- Edit submit script and submit job
 - Edit job name, output, and NAMD file input and file output names to yourfile-min
 - Submit! sbatch min-job-submit.sbatch
 - Should take < 10min
 - Check after about 30 seconds to make sure it's running OK.

Heat/Equilibration

- Collect necessary files
 - **Input files:** yourfile_SICR.pdb, yourfile_Sl.psf
 - **Minimization config file**, named yourfile-hEQ.conf
 - **Parameters:** par_all35m_prot.prm, toppar_water_ions.str
 - **Submit files:** hEQ-job-submit.sbatch
- Get coordinates from last frame of minimization
 - Open yourfile_Sl.psf, and open yourfile-min.dcd into the psf
 - Make sure yourfile_Sl.psf is selected in the "load files for" dropdown before browsing for the yourfile-min.dcd file